holder life

Shrink-fit Heater **HEAT ROBO**

Shrink-fitting temperature is comparatively low, about 300℃[570°F], which is safer for the holders.

Affordable and compact design for simple shrink fitting.

Induction Heater





Hot-air Heater

HEΛT ROBO Baby

- Compact Affordable
- No risk of overheating











	電磁 5000S	電磁2500	電磁12005	
CODE	HRD-02SH	HRD-03	HRD-01S	
Heating method	Induction type			
Rated power consumption	5000w	2500w	1200w	
Rated voltage	3 phases 200-240 v	Single phase 200-240v	100v	
Cutter dia.	φ 3~32 [1/8″~1]	φ 3~16 [1/8″~5/8]	φ 3~12 [1/8″~1/2]	
Heating time (dia 6)	18 sec. (Auto setting)	25 sec.	18 sec.	
Cooling method*	(1min.)			
Size (WxDxH) mm	340×4	230×540×550		

Baby 3000S	Baby 1200S	Baby 1000			
HRB-03S	HRB-02S	HRB-01			
	Hot air type				
3000w	1200w	1000w			
Single phase 200 v	10	0v			
φ 3~32 [1/8″~1]	φ 3~12	[1/8″~1/2]			
70 sec.	120 sec.	180 sec.			
(5min.)	A				
430×330×600	370×260×590	320×160×410			

*About cooling method [O]: Air cooling using factory air. [A]: Cooling operation using air cooling capability of a hot air heater.

■Compatibility table by holder type

MONO series	0	Δ	Δ
2 PIECE type	0	0	0
UNO	0	0	0
HYPER VERSION	0	×	×
STRAIGHT arbor	0	Δ	A

	Δ	×
0	0	0
0	0	×
0	×	×
A	A	×

 $[\]begin{tabular}{ll} \hline \end{tabular} \begin{tabular}{ll} \hline \end{$


*Please verify compatibility for specific holders.

INDUCTION HEATER

DENJI 電磁**5000S**

CODE	Size (W×D×H)	Rated voltage	Kg
HRD-02SH	340×470×750mm	3 phases 200-240 V	30

- ■Option
- •Heating coil(HRD2-CL) •Coil stand
- •Please choose parts on P.15-17
- ■Std. Access.
- •Heat-resistant gloves •Tweezers
- ■Note
 - •Use type HSB/HSC for cutter stopper.
 - Compressed air required: 0.5MPa (air-consumption volume: 245ℓ/min)
 - •The customer should prepare the following items auxiliary parts including the air tube (O.D.: 8mm.) an air filter and a coupler.





Max. Cutter dia. φ3~32 [1/8~1"]

Rated power consumption

5000w

Cutter dia. ϕ 6

Heating 18 sec.

Air-cooling 1 min.

Heating coil (Option)

CODE	Heating coil No.	Holder I.D.	Heating time (Auto setting)	φC	н	Protection sheet for heating coil
HRD2-CL1	1	φ3~ 6 [1/ 8" ~ 1/4]	18 sec.	25	33	HRD2-DN1
-CL2	2	φ7~12*1 [5/16" ~ 1/2]	28 sec.	35	42	-DN2
-CL3	3	φ16, 20%2%3 [5/ 8", 3/4"]	28 sec.	45	47	-DN3
-CL4	4	φ25 [1"] MONO series •MONO 3°[A50M-SLRB20, F63-SLFB20]	40 sec.	55	57	-DN4
-CL5	5	MONO series •MONO 3°[SLRB•SLFB8/10/12/16-M22]	35 sec.	Fig	g. 1	-DN5
-CL6	6	HYPER VERSION •Short type(All sizes) •Heavy-duty type [φ 12, 25]	40 sec.	60	47	-DN6
-CL7	7	φ32, HYPER VERSION •Heavy-duty type [φ20, 25]	60 sec.	70	67	-DN7



Fig. 1 φ58

Protection

HRD2-CL5 Cross-section view

■Std. Access.

- Protection sheet for heating coil
- •The coil protection sheet is a consumable part. Replace the coil protection sheet(option) when you see that it is colored or distorted by the heat

■Caution

- •To protect the heating coil,don't heat a holder without using a coil protection sheet.
- •When ordering, please note that holders for coil 5, 6, or 7 cannot be heated by 2, 3, or 4.
- **1 Use the coil, No.5 for SLRB•SLFB8/10/12-M22. **2 Use the coil, No.5 for SLRB•SLFB16-M22. **3 Use the coil, No.4 for A50M-SLRB20, E50-SLRA16-60-M22,
 - E50-SLRA20-65-M22,F63-SLFB20


DENJI 磁**2500**


One Heating Coil supports dia.3-16mm of shrink-fit holder SLIMLINE. You can escape the inconvenience of changing heating coils.

CODE	AREA	Holder I.D.	Size (W×D×H)	Rated voltage	Kg
HRD-03-L	Japan,	φ3~16 [1/8"~5/8]		Single-phase	30
-s	North America	φ3~ 8 [1/8" ~ 5/16]	470× 750mm	200-240∨	
-LSE	Europe,	φ3~16	7 30 111111		
-SSE	Asia	φ3~ 8			

- ■Option
- •Please choose parts on P.15-17
- ■Std. Access.
 - ●Heat-resistant gloves ●Tweezers
 - Protection sheet for heating coil
- •Use type HSB/HSC for cutter stopper
- •Compressed air required: 0.5MPa (air-consumption volume: 245l/min)
- •The customer should prepare the following items : auxiliary parts including the air tube (O.D.: 8mm.) an air filter and a coupler.

•The HEATROBO DENJI 2500 (HRD-03) is unable to shrink the HYPER version.







Max. Cutter dia. φ3~16 [1/8~5/8"]

Rated power consumption 2500w

Cutter dia. φ6

Heating 25 * sec.

Air-cooling 1 min.

*HRD-03-S/SSE is designed for dia.3 to 8mm. you can shrink-in and out in a short time.

Protection sheet for heating coil

CODE	Shrink-fit Heater
HRD3-DN1	HRD-03-L/LSE
-DN2	-S / SSE

 The coil protection sheet is a consumable part. Replace the coil protection sheet(option) when you see that it is colored or distorted by the heat.

PERIPHERALS



CODE	AREA	Size (W×D×H)	Rated voltage	Kg
HRD-01S	Japan	230×410×550mm	100v	14
-01S-120NA	North America	230×540×550mm	120∨	19
-230AS	Asia		Single phase 230V	

Timer

HEAT

Reheating

OFF


Coil selection

HEAT (Slim type)

Touch Panel

COOL

Base plate



■Option

•Please choose parts on P.15-17

■Std. Access.

- •Heating coil(HRD-CL)
- Heat-resistant gloves

Tweezers

■Note

- •Use type HSB/HSC for cutter stopper.
- •Compressed air required: 0.5MPa
- (air-consumption volume: 245t/min)
 The customer should prepare the following items: auxiliary parts including the air tube (O.D.: 8mm.) an air filter and a coupler.
- •A transformer is required in Europe. Please consult \mbox{MST} about the details of the transformer.

■Caution

The HEATROBO DENJI 1200S (HRD-01S) is unable to shrink certain holders. For details, refer to P.233.

Heating coil

CODE	Heating Coil No.	Holder I.D.	Heating time	φC	Protection sheet for heating coil
HRD-CL1	1	φ3~ 6 [1/ 8" ~ 1/4]	18 sec.	18	HRD-DN1
-CL2	2	φ7~12 [5/16" ~ 1/2]	33 sec.	28	-DN2



■Std. Access.

•Protection sheet for heating coil

•To protect the heating coil,don't heat a holder without using a coil protection sheet.


■Note

The coil protection sheet is a consumable part.
 Replace the coil protection sheet(option) when you see that it is colored or distorted by the heat.

■ Coil stand

For the heating coil of HRD-02SH





*Heating coils are not included.

HOT AIR HEATER

Baby 3000S

CODE	Area	Size (W×D×H)	Rated voltage	Kg
HRB-03S	Japan	430×	Single phase 200 v	9.5
-03S-230NA	North America	330× 600mm	Single phase 230 v	
-230EU	Europe			
-230AS	Asia			

- ■Option
- ϕ 70 Nozzle Please choose parts on P.15-17.
- ■Std. Access.
- ■Note
 - •Compressed air required: 0.5MPa(air-consumption volume: 245 ℓ/min)
 - •Prepare an air tube (O.D.:8mm) and a connection coupling.


■ Shrink-fit heater with the safety timer.


Prevent accidents caused by leaving the heater on.

CODE	Area	Size (W×D×H)	Rated voltage	Kg
HRB-03ST	Japan	430×	Single phase 200 v	9.7
-03ST-230NA	North America	330× 600mm	Single phase 230 v	
-230EU	Europe			
-230AS	Asia			

When heating the SLIMLINE MONO 3°, SLRB32, and the heavy-duty type Hyper Version, the 70mm dia. nozzle HRB-NZL70 is required.









CODE	Area	Size (W×D×H)	Rated voltage	Kg
HRB-02S	Japan	370×260×590 _{mm}	100∨	8.0
-02S-120NA	North America	370×200×390mm	120 v	

- **■**Option
- •Please choose parts on P.15-17.
- ■Std. Access.
- ●Timer ●Heat-resistant gloves ●Tweezers
- ■Note
 •Some holders cannot be used.(P.15)



CODE	Area	Size (W×D×H)	Rated voltage	Kg
HRB-01	Japan	340×160×410 _{mm}	100∨	3.5

- **■**Option
 - •Please choose parts on P.15-17.
- ■Std. Access.
- ●Adapter(ADH-SLK) ●Timer ●Nozzles, 2 pieces (HNZ-17, HNZ-22)
- Heat-resistant gloves
 Tweezers
- ■Note
- A transformer is required in other volfage.
 Please consult MST about the details of the transformer.

Option



CODE BAA-01



Examples of typical uses





■ Adapter

CODE Dimension		Holder		Shrink-Fit Heater model for Use						
CODE	Dimensions		Туре	Screw size	HRD-02SH	HRD-03	HRD-01S	HRB-03S	HRB-02S	HRB-01
		2 PIECE	6 type	М6	0	0	0	0	0	0
	M 8 M 10	type SLIMLINE	8 type	М6						**Adapter (ADH-SLK)
ADH-SLK		collet	12 type	M10						is included.
ADIT SER			ST10	М6						No need to purchasebase (BAA-01) for
	φ88 φ88 φ	STRAIGHT arbor	ST12	М8						2piece collet type 12.
	[O.ONG]		ST16/20/25	M10						,
ADH-HSK25	$E25 = \phi 14$	MONO 3°	E25		0	Δ	Δ	0	Δ	×
-HSK32	E32=¢17 E40=¢21 E50=¢26	MONO CURVE	E32				Some holders cannot be used. Please refer to		**Some holders cannot be used. C (max.) Available dimension C=Max. \$32 **M=22 has a max. diameter of 24 at C.	
-HSK40E		UNO	E40				the dimensional sheet.			
-HSK40A		HYPER VERSION	A40							
-HSK50	0.8kg		A50 / E50 / I	F63						
-40	0.6kg ↓ 63.5 ↓ ↓ 688 ↓ 688		BT40 / A63 F63 / F80 / F DN40 / CT40							
-50	φ100.5 0.5kg φ107		BT50 / A100 DN50 / CT50							
-15TR	15TR=¢19.3 → ◄- S20T=¢22.5 ☐		15TR3							
-S20TR	BT30=\$32		RS20 / S201	ΓR						
-втзо	0.9kg \$88		BT30							
	M10 \	STRAIGHT arbor	ST16/20/25	М10	0	Δ	Δ	0	0	×
BAS-01	M16 M24		ST32 M16			Some holders cannot be used. Please refer to the dimensional				
	0.7kg		ST42	M24			sheet.			
-02	\$10~42 \$\frac{10}{4}\$ \$\frac{1}{24kg}\$\$ \$\phi 102\$		Carbide Sh ST C	ank						

[O] : Available

[X]: Not available

[\triangle] : Restricted use

OTHERS

■ Cutter Stopper

Used as a stopper in the holder when shrink fitting or removing a cutting tool.

HSA_{type} (Coil Spring Type)




CODE	φD	Set Contents(Q'ty)
HSA-D [Ex: HSA-6]	3, 3.175 [1/8"], 4, 5, 6, 7, 8, 9, 10, 11, 12, 16, 20, 25, [3/16", 1/4", 5/16", 3/8", 1/2"]	Each size 10 ea. /SET
-E	3, 4, 6, 8, 10, 12	1ea.,6piecesintotal
-F 3, 4, 5, 6, 7, 8, 9, 10, 11, 12		1 ea. , 10 pieces in total
-EF	3, 4, 5, 6, 8, 10, 12, 16, 20, 25	1 ea. , 10 pieces in total

■Caution

•HSA type cannot be used with HEAT ROBO DENJI.

■ HSB_{type} (Plate Spring Type)



CODE	φD	Set Contents(Q'ty)
HSB-D [Ex: HSB-6]	3, 3.175 [1/8"], 4, 5, 6, 7, 8, 9, 10, 11, 12, 16, 20, 25, 32, [3/16", 1/4", 5/16", 3/8", 1/2", 5/8", 3/4", 1"]	1 ea.
-E	3, 4, 6, 8, 10, 12	1ea.,6piecesintotal
-F 3, 4, 5, 6, 7, 8, 11, 12		1 ea. , 10 pieces in total
-EF 3, 4, 5, 6, 8, 10, 12, 16, 20, 25		1 ea. , 10 pieces in total


■ HSC_{type} (Slit Collet Type)



CODE	φD
HSC-D [Ex: HSC-6]	3, 3.175[1/8"], 4, 6




Insertion Cutter Stopper Overhang length of cutter HEATING Insertion length Safety mark Adjust cutting tool projection or insertion length. The cutter shank should exceed the safety mark.



Simply adjustment for cutting tool projection and insertion length.

Cutter Pliers



Cooling Tray for heated cutting tools

after removal from a holder







Heat-resistant gloves

For additional order


CODE	NOTE
HTB-01	_
-01-R	Right Har
-01-L	Left Han

CODE HAJ-3 10~ 30 3 **-3**.175 3.175 [1/8"]

Cutter Adjuster

-1"

13~ 30 -3/16 [3/16"] -6 6 19~ 45 -1/4 [1/4"] -8 [5/16"] 21~ 55 -10 10 [3/8"] 22~ 70 -12 12 23~ 85 -1/2 [1/2"] -16 16 [5/8"] 26~ 90 -20 20 [3/4"] 37~100 -25 25 40~100



CODE	NOTE
HTB-01	_
-01-R	Right Hand
-01-L	Left Hand

Holder Stand

Cutter Tray

CODE SDH-01 Size:170×170 (mm)

The stand for the SLIMLINE collet, straight arbor and small shank holders (HSK-E25 and E32) is available in four colors, enabling simple color-coding


CODE	Color	Front face	Back face	max.Q'ty
SDKT-RE	RED			
-BL	BLUE	SLIMLINE collet STRAIGHT arbor	Small shank holders (HSK-E25 / E32)	25 pieces
-GR	GREEN			each
-GD	GOLD			


Size:190×190(mm)

















Brush type

■ Cleaning tools

Nylon brushes for internal bores cleaning.

CODE	I.D		
AQC-BR -SET	3 [1/ 8"], 4 [3/16"], 6 [1/4"] 8 [5/16"], 10 [3/ 8"], 12 [1/2"] 1 of each. 6 pieces in total		
-BR 3-5	3 [1/ 8"], 5 pcs.		
-BR 4-5	4 [3/16"], 5 pcs.		
-BR 6-5	6 [1/ 4"], 5 pcs.		
-BR 8-5	8 [5/16"], 5 pcs.		
-BR10-5	10 [3/ 8"], 5 pcs.		
-BR12-5	12 [1/ 2"], 5 pcs.		



■Caution

Do not use when holder is hot.

CWBA01

Adapter (option)

Slide type base

Slide table

Rubber grinding stone type

To eliminate strong oxidized film and burned-in dust and oil that have been generated in the internal bores.

Standard set

CODE	NOTE
CLT-GTA-01	1 ea. of right model
<u> </u>	

Parts

CODE	NAME	φd	Q'ty
CLT-GTA-GP	Grip	_	1
-GTA 3-5		3	5
-GTA 4-5	Rubber	4	5
-GTA 6-5	grindstone	6	5
-GTA 8-5		8	5
-GTA10-5		10	5





Aqua Cool

Aqua cool kit


Cooling kit for cooling SLIMLINE holders after shrink fitting or removing.

CODE	NOTE
AQC-KIT-01	1 ea. for below model

Parts

1 4113		
CODE	NAME	NOTE
AQC-EK-01-2	Special Liquid	2ℓ of undiluted Solution, Use at a dilution ratio of 3%.
-AT-01	Aqua Tray	Drainer plate
-AH-01	Adapter Hanger	Hanger for lowering holders into liquid.
CN -245	Container Box	Size:424×291×245 (364×242×230) mm
-FT	Lid for Container Box	Size:421×288×35 mm

() inside dimension



745

570

CWBA02

(Installed 2 cooling towers)

■ A shrink-fitting work efficiency kit, Shrink-fit holder Chiller

Shrink fitting operation can be shortened. Installation is easy as no power supply is required. All MST's heating devices are available.

Cooling tower

Shrink-fit holder Chiller A type For Induction Heaters and Hot Air Heaters

CODE	Cooling tower	Kg
CWBA01	1 pc.	18
CWBA02	2 pcs.	25

■Std. Access.

- Slide table
- Slide type base(3 pcs.)
- Stopper ring(6 pcs.)
- Thermo seal(7 pcs.)
- Connecting air tube (dia.8mm, length 2m)


■Note


- Compressed air required: 0.5MPa (air-consumption volume: 245 l/min)
- Please connect the air line that came with the unit. (Supply air pressure: 0.5~0.7MPa)

REPLACEMENT PARTS










Stopper

ring







High temperature (over 60°C) Heating

Shrink-fit holder Chiller B type

Compact type that can be installed in tight spots.

- 1 71		
CODE	Kg	
CWBB01	7.3	


■Std. Access.

- Thermo seal(7 pcs.)
- Connecting air tube (dia.8mm, length 2m)

■Note

- •Compressed air required : 0.5MPa
- (air-consumption volume : 245l/min)
 Please connect the air line that came with the unit.

(Supply air pressure : 0.5~0.7MPa)



Shrink-fit holder Chiller C type For Hot Air Heaters

