




縮図 Scale model BT50




SLFB




クーラントスルー対応

Applicable for coolant-through version




HSK-A63


φ8




φ10




φ12




25




φ16



φ20




φ25




HSK-A100

φ12


A100-SLRA12Z-105




A100-SLRA12Z-135




A100-SLRA12Z-165




A100-SLRA12Z-195



A100-SLRB12Z-165
-SLFB12Z-165




A100-SLRB12Z-195
-SLFB12Z-195




φ20


A100-SLRB20Z-105
-SLFB20Z-105



A100-SLRB20Z-135
-SLFB20Z-135




A100-SLRB20Z-165
-SLFB20Z-165




φ25

A100-SLRB25Z-110
-SLFB25Z-110



A100-SLRB25Z-140
-SLFB25Z-140



SLFB




クーラントスルー対応


Applicable for coolant-through version

φ16


A100-SLRA16Z-105




A100-SLRA16Z-135




A100-SLRA16Z-165




A100-SLRA16Z-195



A100-SLRB16Z-165
-SLFB16Z-165



A100-SLRB16Z-195
-SLFB16Z-195



株式会社 **MST** コーポレーション

本社・工場 〒630-0142奈良県生駒市北田原町1738
TEL: 0743-78-1184 e-mail: info@mst-corp.co.jp
<http://www.mst-corp.co.jp>

MST corporation

1738 Kitatahara Ikoma Nara 630-0142 Japan
TEL: 81-743-78-1931 e-mail: info@mst-corp.co.jp
<http://www.mst-corp.co.jp>